



DELUXE COLLECTION

Water Filter Bottle

AQP-FBOT4





Congratulations on your purchase of an AquaPort Water Filter Bottle

Note: Please read through the instructions carefully before using or installing the product and ensure that the manual is kept in a safe place for future reference.

The system must be properly installed and located in accordance with the installation instructions before it is used.

Register your warranty online at www.aquaport.com.au/warranty

CUSTOMER HOTLINE: 1300 764 325

AquaPort Corporation Pty Ltd
PO Box 81 Findon SA 5023 Australia
Telephone: 1300 764 325
Facsimile: 08 8354 0722
Email: aquaport@aquaport.com.au
Web: www.aquaport.com.au

Due to manufacturing alterations actual product may vary from that pictured.

Filter Bottle compatible with most water coolers and water dispensers.

WATER QUALITY

Caution: Do not use with water that is microbiologically unsafe or with water of unknown quality without adequate disinfection before or after the system. This Filter Bottle should only be used with water that has been adequately chlorinated or disinfected. For use with cold water only.

OPERATION CONDITIONS

- All components need to be installed in accordance with user manual instructions for correct performance of unit.
 - Do not filter hot or boiling water through your Filter Bottle.
 - Do not leave water in the bottle for extended periods of time. If water has been left in the bottle for an extended period of time we recommend that you empty the bottle and repeat the steps in Operation Instruction section.
 - Never clean with scouring powders or abrasives.
 - Keep the product away from direct sunlight.
 - Please disassemble and clean the unit every 6 months or when the water flow becomes less apparent. Sanitising sachet packs are available from Aquaport on 1300 764 325 or online at www.aquaport.com.au should you choose to purchase them.
- Replace filter cartridges every 600 liters or 6 months, whichever occurs first, or whenever you detect a change in taste, odour or a decrease in flow.
 - You may see small amounts of black particles at times; these are small pieces of carbon from the filter. These carbon particles are food grade and are not harmful. They will not impair the performance of your filter.

SYSTEM SPECIFICATION

System Specifications	AQP-FBOT4 Water Filter Bottle
Flow Rate	100-400 ml/min
Filter Replacement Model	AQP-FCR-Q
Bottle Capacity	13 litres
Filtered Water Capacity	6.5 litres
Filter Life	600 litres (6 months)*
Reduction Capabilities	Chlorine, Taste & Odour

* Whichever occurs first.

INSTALLATION INSTRUCTIONS

A. Component identification and content check list:

Model AQP-FBOT4 - Water Filter Bottle

Ref	Description	Qty
Cartridges		
1	Filter Cartridges	1
Main Components		
2	Filter Bottle Lid	1
3	Filter Bottle Counter (located inside top of lid)	1
4	Unfiltered water chamber	1
5	Filtered water chamber	1
6	Universal Float Valve	1



OPERATION INSTRUCTIONS

The Aquaport Water Filter Bottle is compatible with most water coolers and water dispensers.

Note: Make sure power is turned off on water cooler before proceeding.

1. Wash all filter bottle parts (except filter cartridge) with warm water and detergent, then rinse out thoroughly.
2. Remove filter cartridge from plastic then immerse filter in ambient water for 20 minutes.
3. If using this product with a water cooler, remove the water cooler bottle supporter.

Note: Most bottle supporters can be removed by twisting bottle supporter in an Anti Clockwise direction or in direction of arrows and pull gently upwards. See Fig 1. example of bottle supporter removed from a water cooler.



4. Screw Universal Float Valve (6) onto the bottom of the Valve Base, located at bottom of the Filtered Water Chamber (5). Screw in clockwise direction.

Note: Do not over tighten.

5. Mount the Filtered Water Chamber (5) vertically onto the water cooler or dispenser. Make sure Water Filter Bottle is sitting firmly in place.
6. Screw the Filter Cartridge (1) into the Unfiltered Water Chamber (4).
7. Mount the Unfiltered Water Chamber (4) into the Filtered Water Chamber (5) and add water to the Unfiltered Water Chamber.

Note: Do not overfill Unfiltered Water Chamber and allow time for water to filter through the filter into the Filtered Water Chamber. First filtration will take longer than subsequent.

8. Place Filter Bottle Lid (2) onto the top of the bottle.
9. Push the button on Digital Filter Replacement Counter (3) to set filter replacement count down.
10. You are now ready to enjoy great tasting water.

FILTER BOTTLE MAINTANENCE

Filter Bottle should be cleaned periodically and filter cartridge should be replaced after 600 litres or 6 months, whichever occurs first, to ensure filters performs as stated.

1. Turn off power on water cooler
2. Remove Filter Bottle away from Water cooler and place over a sink or basin.
3. Sanitise the water cooler or dispenser, with warm water or detergent, and then rinse out thoroughly.

Note: Sanitising Sachet packs are available from AquaPort on 1300 764 325.

4. Wash all filter bottle parts (except filter cartridge) with warm water or detergent and then rinse out thoroughly.
5. Remove filter cartridge from plastic then immerse filter in ambient water for 20 minutes.
6. Proceed with points 4 to 11 in the Operations Instructions replacing the old filter cartridge with the new filter cartridge.

REPLACEMENT FILTERS

Model AQP-FCR-Q

Fig 2



REPLACING FLOAT VALVE



1. Remove the existing Universal Float Valve away from the unit by unscrewing the locking nut away from the filter bottle.
2. Prior to installing the new Universal Float Valve check to ensure the silicon grommet is intact.

IF THIS COMPONENT IS MISSING THE FILTER BOTTLE WILL LEAK AND CREATE AN OVER FLOW ISSUE

3. Insert the new Universal Float Valve into the bottom of the Filtered Water Chamber and tighten the lock nut. Float valve should be assembled **HAND TIGHT** only as it needs to be able to move freely up and down.

TROUBLE SHOOTING

BEFORE YOU CALL FOR SERVICE PLEASE REVIEW THE TROUBLE SHOOTING TIPS FIRST.

Problem	Possible Causes	What To Do
Water leaking between bottle and water machine	Universal float valve not installed correctly	Please unscrew, and re-screw universal float valve to the valve base located at bottom of lower barrel chamber
	Float gasket of universal float valve not completely sealing valve base hole	Push universal float up-wards, check to see if float gasket seals valve base hole completely. If problem persists contact aquaport
Unit leaking	The Unfiltered or Filtered Water Chamber has been overfilled	Remove any excess water that is beyond the lower barrel chamber top
	Universal float valve not installed properly	Check and re-install universal float valve
No water flow through filter cartridges	Filter cartridges have exceeded its longevity	Replace filters
	The water level in filter holder chamber is too low	Fill Unfiltered Water Chamber with water

Your Aquaport 12 Month Repair or Replacement Warranty

Aquaport warrants this appliance to the first purchaser and subject to the stated conditions:

Warranty covers any defects in material or workmanship in the manufactured product within the first twelve months from the date of purchase.

To make a warranty claim you must call Aquaport on toll free number 1300 764 325 for instructions.

If a product is found to be faulty there is a 90 day return policy from the date of purchase. Product returned to store MUST be accompanied by a valid proof of purchase and Customer Reference number received from Aquaport. Call 1300 764 325.

For warranty claims outside of 90 days from date of purchase, product will be repaired or replaced at our discretion. Repair or replacement costs of the product will be covered under warranty by Aquaport.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods.

Warranty does not cover filter cartridge which is a consumable unless proven to have defects in material or workmanship in the manufactured product.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure. Register your warranty online at **www.aquaport.com.au/warranty**

Conditions Of This Warranty:

1. This product has been fully installed in accordance with the user manual installation instructions.
2. The warranty extends only to repairing or replacing any component that proves to be defective in material or workmanship.
3. The warranty does not cover defects occasioned by misuse, alterations, accidents, or used for other than the intended purpose.
4. The warranty does not cover use of this product where water is microbiologically unsafe or of unknown quality, without adequate disinfection before or after the system.
5. The warranty does not cover damage to the product caused by accident, fire, or floods.
6. Proof of purchase is required for warranty claims.

Please keep purchase receipt in a safe place.

To enable us to register your warranty and provide service should a problem occur, we recommend you register your warranty online at **www.aquaport.com.au/warranty**

Aquaport Corporation Pty Ltd

5 John Street Flinders Park,
South Australia 5025

Customer Care 1300 764 325





CUSTOMER HOTLINE: 1300 764 325

AquaPort Corporation Pty Ltd
PO Box 81 Findon SA 5023 Australia
Telephone: 1300 764 325
Facsimile: 08 8354 0722
Email: aquaPort@aquaport.com.au
Web: www.aquaport.com.au